



## Instructions For Positioning MDAS(Magnetic Door Ajar Switch)

### MDAS Installation @ Bottom LEFT Side Frame



- Slide the switch into side frame vertically keeping black lead closest to exposed face /exterior of body.
- Position switch such that center line of MDAS casing aligns with center line of red slat shoe as shown in Fig. 2 when door is fully closed.
- Once switch is aligned, secure MDAS by tightening Phillips screw.


### MDAS Installation @ Bottom RIGHT Side Frame



- Slide the switch into side frame vertically keeping black lead closest to exposed face /exterior of body.
- Position switch such that center line of MDAS casing aligns with center line of red slat shoe as shown in Fig. 4 when door is fully closed.
- Once switch is aligned, secure MDAS by tightening Phillips screw.

## Instructions For Positioning MDAS(Magnetic Door Ajar Switch)


### MDAS Installation @ Top LEFT Side Frame



**Fig. 6**

- Slide the switch into side frame vertically keeping black lead closest to exposed face /exterior of body.
- Position switch such that top face of MDAS casing aligns with center line of red slat shoe as shown in Fig. 6 when door is fully closed.
- Once switch is aligned, secure MDAS by tightening Phillips screw.

### MDAS Installation @ Top RIGHT Side Frame



**Fig. 7**

**Fig. 8**

- Slide the switch into side frame vertically keeping black lead closest to exposed face /exterior of body.
- Position switch such that face of MDAS casing- where leads come out - aligns with top face of red slat shoe as shown in Fig. 8 when door is fully closed.
- Once switch is aligned, secure MDAS by tightening Phillips screw.